



Unité de commande de caméra

## AW-RP50 Pupitre de commande simple et polyvalent

Télécommande compacte et facile à utiliser

### Key Features

Jusqu'à 5 têtes de caméra motorisées pouvant être contrôlées par connexion en série

Multi-contrôle : Jusqu'à 5 AW-RP50 peuvent contrôler simultanément une unité de caméra à distance

Jusqu'à 100 emplacements de mémoire pour préréglages disponibles par caméra

Jusqu'à 100 unités de caméra à distance peuvent être contrôlées par IP et hubs Ethernet

Divers réglages peuvent être configurés depuis un ordinateur (logiciel de configuration fourni)



AW-RP50 Pupitre  
de commande  
simple et  
polyvalent

<https://eu.connect.panasonic.com/fr/fr/products/broadcast-proav/aw-rp50-pupitre-de-commande-simple-et-polyvalent>

<b>Power Supply</b>	DC 12 V ±10 % (AC adaptor provided)
<b>Power Consumption</b>	0.5 A (With DC1 2V)
<b>Poids</b>	Approx. 1.1 kg (Approx.2.4 lbs)
<b>Dimensions (W x H x D)</b>	210 mm x 67 mm x 177 mm (8-1/4 inches x 2-9/16 inches x 6-15/16 inches) (excluding protrusions)
<b>Accessory</b>	AC Adaptor, Power cable
<b>Protocol</b>	IPv4, RS-422 ( Panasonic AW series protocol)
<b>LAN</b>	10BASE-T/100BASE-TX (for IP control)/RJ45 x 1
<b>Température de fonctionnement</b>	0 °C to 40 °C
<b>Operating Humidity</b>	10 % to 90 % ( no condensation)
<b>Connexion</b>	IP : 1
<b>Adjustment Functions</b>	Pan/Tilt, Zoom, Focus, Iris, Gain, Pedestal, Shutter, Detail, White Balance ( Auto, R/B Gain), Black Balance ( Auto, R/B Pedestal), Switch scene files
<b>Preset Memory</b>	Up to 100 sets
<b>Switcher Supported</b>	AW-HS50
<b>Linkage</b>	Camera information display, Tally information imported, Bus material selection (AUX/PWW/PinP/KEY-F), Parameter Changes ( Pan/Tilt lever, Zoom button)
<b>T0 Pan/Tilt Head</b>	RS-422 (for Serial control)/RJ45 x 5
<b>Tally/GPI</b>	TALLY INPUT x 5 channels GPI INPUT x 4 channels GPI OUTPUT x 4 channels/D-sub 15 pin (female) x 1